

Концевые выключатели 9007 T/FT

Технические характеристики

По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70





















Казахстан +(727)345-47-04
























Беларусь +(375)257-127-884




















Узбекистан +998(71)205-18-59





















Киргизия +996(312)96-26-47





















эл.почта: tuq@nt-rt.ru || сайт: <https://telemecanique.nt-rt.ru>

	<u>9007B1</u>	Limit switch lever, 9007, arm t+ft+options
	<u>9007B12</u>	Limit switch lever, 9007, arm t+ft+options
	<u>9007B13</u>	Limit switch lever, 9007, arm t+ft+options
	<u>9007B14</u>	Limit switch lever, 9007, arm t+ft+options
	<u>9007B19</u>	Limit switch lever, 9007, arm t+ft+options
	<u>9007B2</u>	Limit switch lever, 9007, arm t+ft +options
	<u>9007B22</u>	Limit switch lever, 9007, arm t+ft +options
	<u>9007B23</u>	Limit switch lever, 9007, arm t+ft +options
	<u>9007B24</u>	Limit switch lever, 9007, arm t+ft +options
	<u>9007B27</u>	Limit switch lever, 9007, arm t+ft +options
	<u>9007B3</u>	Limit switch lever, 9007, arm t+ft +options
	<u>9007B7</u>	Limit switch lever, 9007, arm t+ft +options
	<u>9007B8</u>	Limit switch lever, 9007, arm t+ft +options
	<u>9007B9</u>	Limit switch lever, 9007, arm t+ft +options
	<u>9007C1</u>	Limit switch lever, 9007, arm t+ft+options
	<u>9007C2</u>	Limit switch lever, 9007, 9007T/FT zinc, fixed length, inside offset steel roller
	<u>9007C3</u>	Limit switch lever, 9007, 9007T/FT zinc, fixed length, inside offset steel roller
	<u>9007DI</u>	Limit switch lever, 9007, arm t+ft+options
	<u>9007DIS1</u>	Limit switch lever arm t+ft special
	<u>9007DIS2</u>	LIMIT SWITCH LEVER ARM T+FT SPECIAL

	9007FTUA4	Limit switch 600 VAC 30amp ft+options
	9007FTUB1	Limit switch, 9007, 600 VAC 12amp t+ft +options
	9007FTUB10	Limit switch, 9007, 600 VAC 12amp ft+options
	9007FTUB12	Limit switch, 9007, 600 VAC 12amp t+ft +options
	9007FTUB12M11	Limit switch, 9007, 600 VAC 12amp t+ft +options
	9007FTUB1M11	Limit switch, 9007, 9007FT foundry universal, spring return, CW only, M20
	9007FTUB1M12	Limit switch, 9007, 9007FT foundry universal, spring return, CW only, PG 13.5
	9007FTUB3	Limit switch, 9007, 9007FT foundry universal, maintained, CW+CCW, 1/2" NPT
	9007FTUB3M11	Limit switch, 9007, 9007FT foundry universal, maintained, CW+CCW, M20
	9007FTUB4	Limit switch, 9007, 600 VAC 12amp t+ft +options
	9007FTUB4M11	Limit switch, 9007, 9007FT foundry universal, spring return, CW+CCW, M20
	9007FTUB4M12	Limit switch, 9007, 9007FT foundry universal, spring return, CW+CCW, PG 13.5
	9007FTUB5	Limit switch, 9007, 9007FT foundry universal, spring return, CCW only, 1/2" NPT
	9007FTUB5M11	Limit switch, 9007, 9007FT foundry universal, spring return, CCW only, M20
	9007FTUC4	Limit switch 600 VAC 30amp ft+options
	9007FTUD1	Limit switch 600 VAC 30amp ft+options
	9007FTUD4	Limit switch 600 VAC 30amp t +options
	9007G10	Limit switch lever, 9007, arm t+ft+options
	9007J2	Limit switch lever, 9007, arm t+ft+options
	9007R16	Limit switch lever, 9007, arm t+ft+options
	9007R17	Limit switch lever, 9007, arm t+ft+options
	9007R18	Limit switch lever, 9007, Snap arm c +options
	9007R19	Limit switch lever, 9007, Snap arm c +options

	<u>9007D2</u>	Limit switch lever, 9007, arm t+ft+options
	<u>9007F4</u>	Limit switch lever, 9007, arm f+fc +options
	<u>9007F5</u>	Limit switch lever, 9007, 9007T/FT zinc, fixed length, inside offset steel roller
	<u>9007F6</u>	Limit switch lever, 9007, arm f+fc +options
	<u>9007FTSB1</u>	Limit switch, 9007, 600 VAC 12amp ft +options
	<u>9007FTSB1M11</u>	Limit switch, 9007, 9007FT foundry standard, spring return, CW+CCW, M20
	<u>9007FTSB2</u>	Limit switch, 9007, 9007FT foundry standard, spring return, CW+CCW, 1/2" NPT
	<u>9007FTSD1</u>	Limit switch 600 VAC 30amp ft+options
	<u>9007FTUA4</u>	Limit switch 600 VAC 30amp ft+options
	<u>9007FTUB1</u>	Limit switch, 9007, 600 VAC 12amp t+ft +options
	<u>9007R20</u>	Limit switch lever, 9007, Snap arm c +options
	<u>9007R21</u>	Limit switch lever, 9007, arm t+ft+options
	<u>9007R22</u>	Limit switch lever, 9007, arm t+ft+options
	<u>9007TSA1</u>	Limit switch, 9007, 600 VAC 20amp t +options
	<u>9007TSB1</u>	Limit switch, 9007, 600 VAC 12amp t +options
	<u>9007TSB1M11</u>	Limit switch, 9007, 9007T mill standard, spring return, CW+CCW, M20
	<u>9007TSB1M12</u>	Limit switch, 9007, 9007T mill standard, spring return, CW+CCW, PG 13.5
	<u>9007TSB3</u>	Limit switch, 9007, 9007T mill standard, spring return, CW+CCW, 1/2" NPT
	<u>9007TSD1</u>	Limit switch, 9007, 600 VAC 12amp t +options

	<u>9007TUA1</u>	Limit switch, 9007, 600 VAC 30amp t +options
	<u>9007TUA5</u>	Limit switch, 9007, 600 VAC 12amp t +options
	<u>9007TUB1</u>	Limit switch, 9007, 600 VAC 12amp t +options
	<u>9007TUB10</u>	Limit switch, 9007, 600 VAC 12amp t +options
	<u>9007TUB12</u>	Limit switch, 9007, 600 VAC 12amp t +options
	<u>9007TUB12M11</u>	Limit switch, 9007, 600 VAC 12amp t +options
	<u>9007TUB1M11</u>	Limit switch, 9007, 9007FT mill universal, spring return, CW only, M20
	<u>9007TUB1M12</u>	Limit switch, 9007, 9007FT mill universal, spring return, CW only, PG 13.5
	<u>9007TUB2M11</u>	Limit switch, 9007, 9007FT mill universal, spring return, CW only, M20
	<u>9007TUB3</u>	Limit switch, 9007, 600 VAC 12amp t +options
	<u>9007TUB3M11</u>	Limit switch, 9007, 9007FT mill universal, maintained, CW+CCW, M20
	<u>9007TUB3M12</u>	Limit switch, 9007, 9007FT mill universal, maintained, CW+CCW, PG 13.5
	<u>9007TUB3S1</u>	LIMIT SWITCH 600VAC 12AMP T +OPTIONS
	<u>9007TUB4</u>	Limit switch, 9007, 600 VAC 12amp t +options
	<u>9007TUB4M11</u>	Limit switch, 9007, 600 VAC 12amp t +options
	<u>9007TUB4M12</u>	Limit switch, 9007, 600 VAC 12amp t +options
	<u>9007TUB5</u>	Limit switch, 9007, 600 VAC 12amp t +options
	<u>9007TUB5M11</u>	Limit switch, 9007, 9007FT mill universal, spring return, CCW, M20
	<u>9007TUB5M12</u>	Limit switch, 9007, 9007FT mill universal, spring return, CCW, PG 13.5
	<u>9007TUB6</u>	Limit switch, 9007, 600 VAC 30amp t +options

	<u>9007TUB7</u>	Limit switch, 9007, 600 VAC 30amp t +options
	<u>9007TUB7M11</u>	Limit switch, 9007, 9007FT mill universal, maintained, CW+CCW, M20
	<u>9007TUB8</u>	Limit switch, 9007, 600 VAC 30amp t +options
	<u>9007TUC1</u>	Limit switch, 9007, 600 VAC 30amp t +options
	<u>9007TUC12</u>	Limit switch, 9007, 600 VAC 30amp t +options
	<u>9007TUC1M12</u>	Limit switch, 9007, 600 VAC 12amp t +options
	<u>9007TUC3</u>	Limit switch, 9007, 600 VAC 30amp t +options
	<u>9007TUC4</u>	Limit switch, 9007, 600 VAC 12amp t +options
	<u>9007TUC4M11</u>	Limit switch, 9007, 600 VAC 12amp t +options
	<u>9007TUC5</u>	Limit switch, 9007, 600 VAC 30amp t +options
	<u>9007TUC5M11</u>	Limit switch, 9007, 600 VAC 12amp t +options
	<u>9007TUD1</u>	Limit switch, 9007, 600 VAC 12amp t +options
	<u>9007TUD12</u>	Limit switch, 9007, 9007FT mill universal, spring return, CW+CCW, 1/2" NPT
	<u>9007TUD4</u>	Limit switch, 9007, 600 VAC 12amp t +options
	<u>9007TUD4M12</u>	Limit switch, 9007, 600 VAC 12amp t +options
	<u>9007TUD5</u>	Limit switch, 9007, 600 VAC 12amp t +options
	<u>9007TUD7</u>	Limit switch, 9007, 600 VAC 30amp t +options
	<u>9007TYD1</u>	Limit switch 600 VAC 25amp t +options
	<u>9007TYD5</u>	Limit switch, 9007, 600 VAC 12amp t +options
	<u>9007X1</u>	Limit switch lever, 9007, Snap arm c +options



[9007X2](#)

Limit switch lever, 9007, arm t+ft +options



[9007Y1](#)

Limit switch lever, 9007, 9007T/FT zinc, 90° fork, RH opposing steel rollers



[9007Y3](#)

Limit switch lever, 9007, arm t+ft+options



[9007Z2](#)

Limit switch lever, 9007, 9007T/FT zinc, 90° fork, LH opposing steel rollers

По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +(727)345-47-04

Беларусь +(375)257-127-884

Узбекистан +998(71)205-18-59

Киргизия +996(312)96-26-47

эл.почта: tuq@nt-rt.ru || сайт: <https://telemecanique.nt-rt.ru>