

Аксессуары

Технические характеристики

По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70






















Казахстан +(727)345-47-04




















Беларусь +(375)257-127-884





















Узбекистан +998(71)205-18-59





















Киргизия +996(312)96-26-47





















эл.почта: tuq@nt-rt.ru || сайт: <https://telemecanique.nt-rt.ru>





















	<u>9006PA30</u>	INDUCTIVE SENSOR MOUNTING BRACKET 30MM
	<u>XSCZ01</u>	Accessory for sensor, IP68 outer cover, for XS7, XS8, XT7
	<u>XSZBI08</u>	Inductive proximity sensors XS, accessory for sensor, Ø 8 mm, fixing clamp with indexing, plastic
	<u>XSZBI12</u>	Inductive proximity sensors XS, accessory for sensor, Å 12 mm, fixing clamp with indexing, plastic
	<u>XSZBI18</u>	Inductive proximity sensors XS, accessory for sensor, Å 18 mm, fixing clamp, plastic, with indexing
	<u>XSZBI30</u>	Inductive proximity sensors XS, accessory for sensor, Å 30 mm, fixing clamp with indexing, plastic
	<u>XSZBD10</u>	Accessory for sensor, replacement bracket
	<u>XSZBE10</u>	Accessory for sensor, replacement bracket
	<u>XSZBS12</u>	Inductive proximity sensors XS, accessory for sensor, fixing bracket, for Ø 12 mm sensor
	<u>XSZBS30</u>	Inductive proximity sensors XS, accessory for sensor, fixing bracket, for Å 30 mm sensor
	<u>XSZEI12</u>	Accessory for sensor, fixing nuts, chromium plated steel, Ø 12 mm
	<u>XZCC12FCP42B</u>	Female, M12, 4 pin, elbowed connector, cable gland Pg 7
	<u>XZCC12FDB50R</u>	Female, M12, 5 pin, shielded straight connector
	<u>XZCC12FDM40B</u>	Female, M12, 4 pin, straight connector, cable gland Pg 7
	<u>XZCC12FDM50B</u>	Female, M12, 5 pin, straight connector, cable gland Pg 7
	<u>XZCC12FDP40B</u>	Female, M12, 4 pin, straight connector, cable gland Pg 7
	<u>XZCC12MCM40B</u>	Male, M12, 4 pin, elbowed connector, cable gland Pg 7
	<u>XZCC12MCM50B</u>	Male, M12, 5 pin, elbowed connector, cable gland Pg 7
	<u>XZCC12MCP40B</u>	Male, M12, 4 pin, elbowed connector, cable gland Pg 7
	<u>XZCC12MDB50R</u>	Male, M12, 5 pin, shielded straight connector
	<u>XZCC12MDM40B</u>	Male, M12, 4 pin, straight connector, cable gland Pg 7















	<u>XSZE118</u>	Accessory for sensor, fixing nuts, chromium plated steel, Ø 18 mm
	<u>XSZE130</u>	Accessory for sensor, fixing nuts, chromium plated steel, Ø 30 mm
	<u>XSZPI12</u>	Accessory for sensor, CNOMO cable sleeve adaptor M12
	<u>XSZQTL12</u>	Accessory for sensor, adaptor Ø 12 mm, for XS, XT
	<u>XZSN18</u>	Accessory for sensor, spring return, 18 mm
	<u>XZSN30</u>	Accessory for sensor, spring return, 30 mm
	<u>XZCC12FCM40B</u>	Female, M12, 4 pin, elbowed connector, cable gland Pg 7
	<u>XZCC12FCM50B</u>	Female, M12, 5 pin, elbowed connector, cable gland Pg 7
	<u>XZCC12FCP40B</u>	Female, M12, 4 pin, elbowed connector, cable gland Pg 7
	<u>XZCC12MDM50B</u>	Male, M12, 5 pin, straight connector, cable gland Pg 7
	<u>XZCC12MDP40B</u>	Male, M12, 4 pin, straight connector, cable gland Pg 7
	<u>XZCC18FCP40B</u>	Female, M18, 4 pin, elbowed connector, cable gland Pg 9
	<u>XZCC18FDP40B</u>	Female, M18, 4 pin, straight connector, cable gland Pg 9
	<u>XZCC20FCM30B</u>	Female, 1/2 20UNF, 3 pin, elbowed connector, cable gland Pg 7
	<u>XZCC20FDM30B</u>	Female, 1/2 20UNF, 3 pin, straight connector, cable gland Pg 7
	<u>XZCC20MCM30B</u>	Male, 1/2 20UNF, 3 pin, elbowed connector, cable gland Pg 7
	<u>XZCC20MDM30B</u>	Male, 1/2 20UNF, 3 pin, straight connector, cable gland Pg 7
	<u>XZCC43FCP40B</u>	Female, DIN 43650 A, 4 pin, elbowed connector, cable gland Pg 11
	<u>XZCC8FCM30S</u>	Female, M8, 3 pin, elbowed connector, cable gland M9.5 x 1

	<u>XZCC8FCM30V</u>	Female, M8, 3 pin, elbowed connector, cable gland M9.5 x 1
	<u>XZCC8FCM40S</u>	Female, M8, 4 pin, elbowed connector, cable gland M9.5 x 1
	<u>XZCC8FCM40V</u>	Female, M8, 4 pin, elbowed connector, cable gland M9.5 x 1
	<u>XZCC8FDM30S</u>	Female, M8, 3 pin, straight connector, cable gland M9.5 x 1
	<u>XZCC8FDM30V</u>	Female, M8, 3 pin, straight connector, cable gland M9.5 x 1
	<u>XZCC8FDM40S</u>	Female, M8, 4 pin, straight connector, cable gland M9.5 x 1
	<u>XZCC8FDM40V</u>	Female, M8, 4 pin, straight connector, cable gland M9.5 x 1
	<u>XZCC8MDM30V</u>	Male, M8, 3 pin, straight connector, cable gland M9.5 x 1
	<u>XZCP0166L10</u>	Pre wired connectors XZ, straight female, Ø 8 mm, 3 pins, cable PUR 10 m
	<u>XZCP0166L2</u>	Pre wired connectors XZ, straight female, Ø 8 mm, 3 pins, cable PUR 2 m
	<u>XZCP0166L5</u>	Pre wired connectors XZ, straight female, Ø 8 mm, 3 pins, cable PUR 5 m
	<u>XZCP0266L10</u>	Pre wired connectors XZ, elbowed female, Ø 8 mm, 3 pins, cable PUR 10 m
	<u>XZCP0266L2</u>	Pre wired connectors XZ, elbowed female, Ø 8 mm, 3 pins, cable PUR 2 m
	<u>XZCP0266L5</u>	Pre wired connectors XZ, elbowed female, Ø 8 mm, 3 pins, cable PUR 5 m
	<u>XZCP0366L10</u>	Pre wired connectors XZ, elbowed female, Ø 8 mm, 3 pins, cable PUR 10 m
	<u>XZCP0366L2</u>	Pre wired connectors XZ, elbowed female, Ø 8 mm, 3 pins, cable PUR 2 m
	<u>XZCP0366L5</u>	Pre wired connectors XZ, elbowed female, Ø 8 mm, 3 pins, cable PUR 5 m
	<u>XZCP0466L2</u>	Pre wired connectors XZ, elbowed female, Ø 8 mm, 3 pins, cable PUR 2 m
	<u>XZCP0466L5</u>	Pre wired connectors XZ, elbowed female, Ø 8 mm, 3 pins, cable PUR 5 m
	<u>XZCP0566L10</u>	Pre wired connectors XZ, straight female, M8, 3 pins, cable PUR 10 m

	<u>XZCP0941L10</u>	Pre wired connectors XZ, straight female, M8, 4 pins, cable PUR 10 m
	<u>XZCP0941L15</u>	Pre wired connectors XZ, straight female, M8, 4 pins, cable PUR 15 m
	<u>XZCP0941L2</u>	Pre wired connectors XZ, straight female, M8, 4 pins, cable PUR 2 m
	<u>XZCP0941L5</u>	Pre wired connectors XZ, straight female, M8, 4 pins, cable PUR 5 m
	<u>XZCP1041L10</u>	Pre wired connectors XZ, elbowed female, M8, 4 pins, cable PUR 10 m
	<u>XZCP1041L2</u>	Pre wired connectors XZ, elbowed female, M8, 4 pins, cable PUR 2 m
	<u>XZCP1041L5</u>	Pre wired connectors XZ, elbowed female, M8, 4 pins, cable PUR 5 m
	<u>XZCP1141L10</u>	Pre wired connectors XZ, straight female, M12, 4 pins, cable PUR 10 m
	<u>XZCP1141L15</u>	Pre wired connectors XZ, straight female, M12, 4 pins, cable PUR 15 m
	<u>XZCP1141L2</u>	Pre wired connectors XZ, straight female, M12, 4 pins, cable PUR 2 m
	<u>XZCP0566L2</u>	Pre wired connectors XZ, straight female, M8, 3 pins, cable PUR 2 m
	<u>XZCP0566L5</u>	Pre wired connectors XZ, straight female, M8, 3 pins, cable PUR 5 m
	<u>XZCP0666L10</u>	Pre wired connectors XZ, elbowed female, M8, 3 pins, cable PUR 10 m
	<u>XZCP0666L2</u>	Pre wired connectors XZ, elbowed female, M8, 3 pins, cable PUR 2 m
	<u>XZCP0666L5</u>	Pre wired connectors XZ, elbowed female, M8, 3 pins, cable PUR 5 m
	<u>XZCP0766L10</u>	Pre wired connectors XZ, elbowed female, M8, 3 pins, cable PUR 10 m
	<u>XZCP0766L2</u>	Pre wired connectors XZ, elbowed female, M8, 3 pins, cable PUR 2 m
	<u>XZCP0766L5</u>	Pre wired connectors XZ, elbowed female, M8, 3 pins, cable PUR 5 m
	<u>XZCP0866L2</u>	Pre wired connectors XZ, elbowed female, M8, 3 pins, cable PUR 2 m
	<u>XZCP0866L5</u>	Pre wired connectors XZ, elbowed female, M8, 3 pins, cable PUR 5 m

	<u>XZCP1440L10</u>	Pre wired connectors XZ, elbowed female, M12, 3 pins, cable PUR 10 m
	<u>XZCP1440L2</u>	Pre wired connectors XZ, elbowed female, M12, 3 pins, cable PUR 2 m
	<u>XZCP1440L5</u>	Pre wired connectors XZ, elbowed female, M12, 3 pins, cable PUR 5 m
	<u>XZCP1541L05</u>	Pre wired connectors XZ, straight male, M12, 4 pins, cable PUR 0.5 m
	<u>XZCP1541L1</u>	Pre wired connectors XZ, straight male, M12, 4 pins, cable PUR 1 m
	<u>XZCP1541L2</u>	Pre wired connectors XZ, straight male, M12, 4 pins, cable PUR 2 m
	<u>XZCP1564L05</u>	Pre wired connectors XZ, straight male, M12, 5 pins, cable PUR 0.5 m
	<u>XZCP1564L1</u>	Pre wired connectors XZ, straight male, M12, 5 pins, cable PUR 1 m
	<u>XZCP1564L10</u>	Pre wired connectors XZ, straight male, M12, 5 pins, cable PUR 10 m
	<u>XZCP1564L2</u>	Pre wired connectors XZ, straight male, M12, 5 pins, cable PUR 2 m
	<u>XZCP1564L20</u>	Pre wired connectors XZ, straight male, M12, 5 pins, cable PUR 20 m
	<u>XZCP1564L5</u>	Pre wired connectors XZ, straight male, M12, 5 pins, cable PUR 5 m
	<u>XZCP1662L2</u>	Pre wired connectors XZ, straight female, 7/8"16 UN, 3 pins, cable PUR 2 m
	<u>XZCP1662L5</u>	Pre wired connectors XZ, straight female, 7/8"16 UN, 3 pins, cable PUR 5 m
	<u>XZCP1670L10</u>	Pre wired connectors XZ, straight female, 7/8"16 UN, 3 pins, cable PUR 10 m
	<u>XZCP1670L2</u>	Pre wired connectors XZ, straight female, 7/8"16 UN, 3 pins, cable PUR 2 m
	<u>XZCP1670L5</u>	Pre wired connectors XZ, straight female, 7/8"16 UN, 3 pins, cable PUR 5 m
	<u>XZCP1764L10</u>	Pre wired connectors XZ, straight female, 7/8"16 UN, 5 pins, cable PUR 10 m
	<u>XZCP1764L2</u>	Pre wired connectors XZ, straight female, 7/8"16 UN, 5 pins, cable PUR 2 m
	<u>XZCP1764L5</u>	Pre wired connectors XZ, straight female, 7/8"16 UN, 5 pins, cable PUR 5 m

	<u>XZCP2737L1</u>	Pre wired connectors XZ, straight male, M8, 3 pins, cable PUR 1 m
	<u>XZCP2737L2</u>	Pre wired connectors XZ, straight male, M8, 3 pins, cable PUR 2 m
	<u>XZCP29P1I10</u>	Pre wired connectors XZ, straight female, M12, 8 pins, cable PUR 10 m
	<u>XZCP29P1I2</u>	Pre wired connectors XZ, straight female, M12, 8 pins, cable PUR 2 m
	<u>XZCP29P1I5</u>	Pre wired connectors XZ, straight female, M12, 8 pins, cable PUR 5 m
	<u>XZCP29P12I10</u>	Pre wired connectors XZ, straight female, M12, 8 pins, cable PUR 10 m
	<u>XZCP29P12L2</u>	Pre wired connectors XZ, straight female, M12, 8 pins, cable PUR 2 m
	<u>XZCP29P12L5</u>	Pre wired connectors XZ, straight female, M12, 8 pins, cable PUR 5 m
	<u>XZCPA0566L10</u>	Pre wired connectors XZ, straight female, M8, 3 pins, cable PUR 10 m
	<u>XZCPA0566L5</u>	Pre wired connectors XZ, straight female, M8, 3 pins, cable PUR 5 m
	<u>XZCPA094I10</u>	Pre wired connectors XZ, straight female, M8, 4 pins, cable PVC 10 m
	<u>XZCPA094I5</u>	Pre wired connectors XZ, straight female, M8, 4 pins, cable PVC 5 m
	<u>XZCPA114I10</u>	Pre wired connectors XZ, straight female, M12, 4 pins, cable PVC 10 m
	<u>XZCPA114I2</u>	Pre wired connectors XZ, straight female, M12, 4 pins, cable PVC 2 m
	<u>XZCPA114I5</u>	Pre wired connectors XZ, straight female, M12, 4 pins, cable PVC 5 m
	<u>XZCPA1164L10</u>	Pre wired connectors XZ, elbowed female, M12, 5 pins, cable PVC 10 m
	<u>XZCPA1164L5</u>	Pre wired connectors XZ, elbowed female, M12, 5 pins, cable PVC 5 m
	<u>XZCPA124I10</u>	Pre wired connectors XZ, elbowed female, M12, 4 pins, cable PVC 10 m
	<u>XZCPA124I2</u>	Pre wired connectors XZ, elbowed female, M12, 4 pins, cable PVC 2 m
	<u>XZCPA124I5</u>	Pre wired connectors XZ, elbowed female, M12, 4 pins, cable PVC 5 m

	<u>XZCP1865L10</u>	Pre wired connectors XZ, straight female, 1/2"20 UNF, 3 pins, cable PUR 10 m
	<u>XZCP1865L2</u>	Pre wired connectors XZ, straight female, 1/2"20 UNF, 3 pins, cable PUR 2 m
	<u>XZCP1865L5</u>	Pre wired connectors XZ, straight female, 1/2"20 UNF, 3 pins, cable PUR 5 m
	<u>XZCP1965L10</u>	Pre wired connectors XZ, elbowed female, 1/2"20 UNF, 3 pins, cable PUR 10 m
	<u>XZCP1965L2</u>	Pre wired connectors XZ, elbowed female, 1/2"20 UNF, 3 pins, cable PUR 2 m
	<u>XZCP1965L5</u>	Pre wired connectors XZ, elbowed female, 1/2"20 UNF, 3 pins, cable PUR 5 m
	<u>XZCP2540L10</u>	Pre wired connectors XZ, elbowed female, M12, 3 pins, cable PUR 10 m
	<u>XZCP2540L2</u>	Pre wired connectors XZ, elbowed female, M12, 3 pins, cable PUR 2 m
	<u>XZCP2540L5</u>	Pre wired connectors XZ, elbowed female, M12, 3 pins, cable PUR 5 m
	<u>XZCP2737L05</u>	Pre wired connectors XZ, straight male, M8, 3 pins, cable PUR 0.5 m
	<u>XZCPA1865L10</u>	Pre wired connectors XZ, straight female, 1/2"20 UNF, 3 pins, cable PVC 10 m
	<u>XZCPA1865L5</u>	Pre wired connectors XZ, straight female, 1/2"20 UNF, 3 pins, cable PVC 5 m
	<u>XZCPA1965L10</u>	Pre wired connectors XZ, elbowed female, 1/2"20 UNF, 3 pins, cable PVC 10 m
	<u>XZCPA1965L5</u>	Pre wired connectors XZ, elbowed female, 1/2"20 UNF, 3 pins, cable PVC 5 m

По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +(727)345-47-04

Беларусь +(375)257-127-884

Узбекистан +998(71)205-18-59

Киргизия +996(312)96-26-47

эл.почта: tuq@nt-rt.ru || сайт: <https://telemecanique.nt-rt.ru>