

Лазеры общего назначения

Технические характеристики

По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70




















Казахстан +(727)345-47-04





















Беларусь +(375)257-127-884





















Узбекистан +998(71)205-18-59





















Киргизия +996(312)96-26-47





















эл.почта: tuq@nt-rt.ru || сайт: <https://telemecanique.nt-rt.ru>













	<u>XU2M18MC230WT</u>	Photoelectric sensors XU, XU2, emitter, 90°, 24...240VAC/DC
	<u>XUBLANCNL2</u>	Photoelectric sensors XU, XUB, thru beam, laser, Sn 100 m, 12...24 VDC, cable 2 m
	<u>XUBLANCNM12</u>	Photoelectric sensors XU, XUB, thru beam, laser, Sn 100 m, 12...24 VDC, M12
	<u>XUBLAPCNL2</u>	Photoelectric sensors XU, XUB, thru beam, laser, Sn 100 m, 12...24 VDC, cable 2 m
	<u>XUBLAPCNM12</u>	Photoelectric sensors XU, XUB, thru beam, laser, Sn 100 m, 12...24 VDC, M12
	<u>XUBLBNCNM12</u>	Photoelectric sensors XU, XUB, thru beam, laser, Sn 100 m, 12...24 VDC, M12
	<u>XUBLBPCNL2</u>	Photoelectric sensors XU, XUB, thru beam, laser, Sn 100 m, 12...24 VDC, cable 2 m
	<u>XUBLBPCNM12</u>	Photoelectric sensors XU, XUB, thru beam, laser, Sn 100 m, 12...24 VDC, M12
	<u>XUFN01321</u>	Photoelectric sensors XU, plastic fibre optic for sensor, diffuse, positioning, standard, 2 m, Sn18mm
	<u>XUK8TAE1MM12</u>	Photoelectric sensors XU, XUK, diffuse, Sn 5 m Iout IOLINK or auto PNP/NPN, Iout 0...10 V
	<u>XUK8TAE1MM12</u>	Photoelectric sensors XU, XUK, diffuse, Sn 5 m Iout IOLINK or auto PNP/NPN, Iout 0...10 V
	<u>XUK8TAE2MM12</u>	Photoelectric sensors XU, XUK, diffuse Sn 5 m Iout IOLINK or auto PNP/NPN, Iout 4.20 mA
	<u>XUK8TAE2MM12</u>	Photoelectric sensors XU, XUK, diffuse Sn 5 m Iout IOLINK or auto PNP/NPN, Iout 4.20 mA
	<u>XUK8TAKDMM12</u>	Photoelectric sensors XU, XUK, diffuse, Sn 5 m Iout IOLINK or auto PNP/NPN, Iout auto PNP/NPN
	<u>XUK8TAKDMM12</u>	Photoelectric sensors XU, XUK, diffuse, Sn 5 m Iout IOLINK or auto PNP/NPN, Iout auto PNP/NPN
	<u>XUK8TAKSMM12</u>	Photoelectric sensors XU, XUK, diffuse, Sn 5 m Iout IOLINK or auto PNP/NPN
	<u>XUK8TAKSMM12</u>	Photoelectric sensors XU, XUK, diffuse, Sn 5 m Iout IOLINK or auto PNP/NPN
	<u>XUK9LAPSMM12</u>	Photoelectric sensors XU, photo electric laser sensor, XUK, polarised reflex, Sn 14 m, 10...30 VDC, M12
	<u>XUK9TAH2MM12</u>	Photoelectric sensors XU, photo electric laser sensor, XUK, reflex, Sn 70 m, 2Q 1Qa 3IN, hoisting app

	<u>XUFN05321</u>	Photoelectric sensors XU, plastic fibre optic for sensor, diffuse, general use, standard, 2 m, Sn70mm
	<u>XUFN05321L3</u>	Photoelectric sensors XU, plastic fibre optic for sensor, diffuse, general use, standard, 3 m, Sn70mm
	<u>XUFN05323</u>	Photoelectric sensors XU, plastic fibre optic for sensor, diffuse, positioning, standard, 2 m, Sn60mm
	<u>XUFN12301</u>	Photoelectric sensors XU, plastic fibre optic for sensor, thru beam, general use, std., 2 m, Sn200mm
	<u>XUFN12301L10</u>	Photoelectric sensors XU, plastic fibre optic for sensor, thru beam, general use, std., 10 m, Sn200mm
	<u>XUFN2P01L2</u>	Photoelectric sensors XU, plastic fibre optic for sensor, thru beam, long sensing, 2 m, Sn300mm
	<u>XUK2LAKSMMI2T</u>	Photoelectric sensors XU, photo electric laser sensor, XUK, thru beam transmitter, Sn 30 m -10...30 VDC, M12
	<u>XUK2LAPSMMI2R</u>	Photoelectric sensors XU, photo electric laser sensor, XUK, thru beam receiver, Sn 30 m, 10...30 VDC, M12
	<u>XUK5LAPSMMI2</u>	Photoelectric sensors XU, photo electric laser sensor, XUK, diffuse energetic, Sn 1,2 m, 10...30 VDC, M12
	<u>XUK8LAPPNM12</u>	Photoelectric sensors XU, photo electric laser sensor, XUK, background suppression, Sn 0,8 m -10...30 VDC M12
	<u>XUK9TAH2MM12</u>	Photoelectric sensors XU, photo electric laser sensor, XUK, reflex, Sn 70 m, 2Q 1Qa 3IN, hoisting app
	<u>XUM5ALAYL2</u>	Photoelectric sensors XUM5, Diffuse, Laser, Sn 250mm, IO-Link, Cable 2m
	<u>XUM5ALAYM8</u>	Photoelectric sensors XUM5, Diffuse, Laser, Sn 250mm, IO-Link, Connetor M8
	<u>XUM5ALAYP015</u>	Photoelectric sensors XUM5, Diffuse, Laser, Sn 250mm, IO-Link, Pigtail M8 15cm
	<u>XUM8ALAYL2</u>	Photoelectric sensors XUM8, BGS, Laser, Sn 150mm, IO-Link, Cable 2m
	<u>XUM8ALAYM8</u>	Photoelectric sensors XUM8, BGS, Laser, Sn 150mm, IO-Link, Connector M8
	<u>XUM8ALAYP015</u>	Photoelectric sensors XUM8, BGS, Laser, Sn 150mm, IO-Link, Pigtail M12 15cm
	<u>XUM9ALAYL2</u>	Photoelectric sensors XUM9, Reflex, Laser, Sn 13000mm, IO-Link, Cable 2m
	<u>XUM9ALAYM8</u>	Photoelectric sensors XUM9, Reflex, Laser, Sn 13000mm, IO-Link, Connector M8
	<u>XUM9ALAYP015</u>	Photoelectric sensors XUM9, Reflex, Laser, Sn 13000mm, IO-Link, Pigtail M12 15cm

	<u>XUZA51S</u>	Fixing bracket, Photoelectric sensors XU, accessory for sensor, XUK S, stainless steel
	<u>XUZA51S</u>	Fixing bracket, Photoelectric sensors XU, accessory for sensor, XUK S, stainless steel
	<u>XUZA51S</u>	Fixing bracket, Photoelectric sensors XU, accessory for sensor, XUK S, stainless steel
	<u>XUZA51S</u>	Fixing bracket, Photoelectric sensors XU, accessory for sensor, XUK S, stainless steel
	<u>XUZASK001</u>	Fixing bracket, Photoelectric sensors XU, accessory for sensor, XUK laser, angle protective
	<u>XUZASK002</u>	Fixing bracket, Photoelectric sensors XU, accessory for sensor, XUK laser, dovetail
	<u>XUZASK004</u>	Fixing bracket, Photoelectric sensors XU, accessory for sensor, XUK laser + TOF, angle fine adjustable
	<u>XUZASK004</u>	Fixing bracket, Photoelectric sensors XU, accessory for sensor, XUK laser + TOF, angle fine adjustable
	<u>XUZASW001</u>	accessory for sensors - XUW - dovetail fixing clamp - 1 axe
	<u>XUZASW001</u>	accessory for sensors - XUW - dovetail fixing clamp - 1 axe
	<u>XUT8ALAYL2</u>	Photoelectric sensors XUT8, BGS, Laser, Sn 70mm, IO-Link, Cable 2m
	<u>XUT8ALAYP02</u>	Photoelectric sensors XUT8, BGS, Laser, Sn 70mm, IO-Link, Pigtail M8 20cm
	<u>XUT9ALPXL2</u>	Photoelectric sensors XUT9, Reflex, Laser, Sn 3000mm, IO-Link, Cable 2m
	<u>XUT9ALXP02</u>	Photoelectric sensors XUT9, Reflex, Laser, Sn 3000mm, IO-Link, Pigtail M8 20cm
	<u>XUYPCO925LIANSP</u>	Photoelectric sensors XU, XUY, diffuse, analog laser, Sn 60 mm, 12...24 VDC, M12
	<u>XUYPCO925L2ANSP</u>	Photoelectric sensors XU, XUY, diffuse, analog laser, Sn 85 mm, 12...24 VDC, M12
	<u>XUYPCO925L3ANSP</u>	Photoelectric sensors XU, XUY, diffuse, analog laser, Sn 0.3 m, 12...24 VDC, M12
	<u>XUYPSILCO965S</u>	Photoelectric sensors XU, XUY, BGS, laser, Sn 300 mm, 12...24 VDC, M8
	<u>XUYPSCO929L2SP</u>	Photoelectric sensors XU, XUY 929, BGS, laser, Sn 110 mm, 12...24 VDC, M8
	<u>XUZA51S</u>	Fixing bracket, Photoelectric sensors XU, accessory for sensor, XUK S, stainless steel

	<u>XUZASW002</u>	accessory for sensors - XUW - fixing bracket - metal
	<u>XUZASW002</u>	accessory for sensors - XUW - fixing bracket - metal
	<u>XUZC250</u>	Photoelectric sensors XU, accessory for sensor, adhesive reflector, 250x250mm
	<u>XUZC250</u>	Photoelectric sensors XU, accessory for sensor, adhesive reflector, 250x250mm
	<u>XZCC12FCM40B</u>	Female, M12, 4 pin, elbowed connector, cable gland Pg 7
	<u>XZCC12FCM50B</u>	Female, M12, 5 pin, elbowed connector, cable gland Pg 7
	<u>XZCC12FCP40B</u>	Female, M12, 4 pin, elbowed connector, cable gland Pg 7
	<u>XZCC12FCP42B</u>	Female, M12, 4 pin, elbowed connector, cable gland Pg 7
	<u>XZCC12FDB50R</u>	Female, M12, 5 pin, shielded straight connector
	<u>XZCC12FDM40B</u>	Female, M12, 4 pin, straight connector, cable gland Pg 7
	<u>XZCC12FDM50B</u>	Female, M12, 5 pin, straight connector, cable gland Pg 7
	<u>XZCC12FDP40B</u>	Female, M12, 4 pin, straight connector, cable gland Pg 7
	<u>XZCC8FCM40S</u>	Female, M8, 4 pin, elbowed connector, cable gland M9.5 x 1
	<u>XZCC8FCM40V</u>	Female, M8, 4 pin, elbowed connector, cable gland M9.5 x 1
	<u>XZCC8FDM40S</u>	Female, M8, 4 pin, straight connector, cable gland M9.5 x 1
	<u>XZCC8FDM40V</u>	Female, M8, 4 pin, straight connector, cable gland M9.5 x 1
	<u>XZCP0941L10</u>	Pre wired connectors XZ, straight female, M8, 4 pins, cable PUR 10 m
	<u>XZCP0941L15</u>	Pre wired connectors XZ, straight female, M8, 4 pins, cable PUR 15 m
	<u>XZCP0941L2</u>	Pre wired connectors XZ, straight female, M8, 4 pins, cable PUR 2 m
	<u>XZCP0941L5</u>	Pre wired connectors XZ, straight female, M8, 4 pins, cable PUR 5 m

	<u>XZCP1041L10</u>	Pre wired connectors XZ, elbowed female, M8, 4 pins, cable PUR 10 m
	<u>XZCP1041L2</u>	Pre wired connectors XZ, elbowed female, M8, 4 pins, cable PUR 2 m
	<u>XZCP1041L5</u>	Pre wired connectors XZ, elbowed female, M8, 4 pins, cable PUR 5 m
	<u>XZCP1141L10</u>	Pre wired connectors XZ, straight female, M12, 4 pins, cable PUR 10 m
	<u>XZCP1141L15</u>	Pre wired connectors XZ, straight female, M12, 4 pins, cable PUR 15 m
	<u>XZCP1141L2</u>	Pre wired connectors XZ, straight female, M12, 4 pins, cable PUR 2 m
	<u>XZCP1141L20</u>	Pre wired connectors XZ, straight female, M12, 4 pins, cable PUR 20 m
	<u>XZCP1141L5</u>	Pre wired connectors XZ, straight female, M12, 4 pins, cable PUR 5 m
	<u>XZCP1164L10</u>	Pre wired connectors XZ, straight female, M12, 5 pins, cable PUR 10 m
	<u>XZCP1164L2</u>	Pre wired connectors XZ, straight female, M12, 5 pins, cable PUR 2 m
	<u>XZCP1164L5</u>	Pre wired connectors XZ, straight female, M12, 5 pins, cable PUR 5 m
	<u>XZCP1169L10</u>	Pre wired connectors XZ, straight female, M12, 4 pins, cable PUR 10 m
	<u>XZCP1169L2</u>	Pre wired connectors XZ, straight female, M12, 4 pins, cable PUR 2 m
	<u>XZCP1169L5</u>	Pre wired connectors XZ, straight female, M12, 4 pins, cable PUR 5 m
	<u>XZCP1241L10</u>	Pre wired connectors XZ, elbowed female, M12, 4 pins, cable PUR 10 m
	<u>XZCP1241L15</u>	Pre wired connectors XZ, elbowed female, M12, 4 pins, cable PUR 15 m
	<u>XZCP1241L2</u>	Pre wired connectors XZ, elbowed female, M12, 4 pins, cable PUR 2 m
	<u>XZCP1241L20</u>	Pre wired connectors XZ, elbowed female, M12, 4 pins, cable PUR 20 m
	<u>XZCP1241L25</u>	Pre wired connectors XZ, elbowed female, M12, 4 pins, cable PUR 25 m
	<u>XZCP1241L5</u>	Pre wired connectors XZ, elbowed female, M12, 4 pins, cable PUR 5 m

	<u>XZCP1264L10</u>	Pre wired connectors XZ, elbowed female, M12, 5 pins, cable PUR 10 m
	<u>XZCP1264L2</u>	Pre wired connectors XZ, elbowed female, M12, 5 pins, cable PUR 2 m
	<u>XZCP1264L5</u>	Pre wired connectors XZ, elbowed female, M12, 5 pins, cable PUR 5 m
	<u>XZCP29P12L10</u>	Pre wired connectors XZ, straight female, M12, 8 pins, cable PUR 10 m
	<u>XZCP29P12L2</u>	Pre wired connectors XZ, straight female, M12, 8 pins, cable PUR 2 m
	<u>XZCP29P12L5</u>	Pre wired connectors XZ, straight female, M12, 8 pins, cable PUR 5 m
	<u>XZCPV11V12L10</u>	Pre wired connectors XZ, straight female, M12, 5 pins, cable PVC 10 m
	<u>XZCPV11V12L2</u>	Pre wired connectors XZ, straight female, M12, 5 pins, cable PVC 2 m
	<u>XZCPV11V12L5</u>	Pre wired connectors XZ, straight female, M12, 5 pins, cable PVC 5 m
	<u>XZCPV12V12L10</u>	Pre wired connectors XZ, elbowed female, M12, 5 pins, cable PVC 10 m
	<u>XZCPV12V12L2</u>	Pre wired connectors XZ, elbowed female, M12, 5 pins, cable PVC 2 m
	<u>XZCPV12V12L5</u>	Pre wired connectors XZ, elbowed female, M12, 5 pins, cable PVC 5 m

По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +(727)345-47-04

Беларусь +(375)257-127-884

Узбекистан +998(71)205-18-59

Киргизия +996(312)96-26-47

эл.почта: tuq@nt-rt.ru || сайт: <https://telemecanique.nt-rt.ru>