

# Простые аварийные выключатели STOP ROPE PULL

## Технические характеристики

По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04  
Ангарск (3955)60-70-56  
Архангельск (8182)63-90-72  
Астрахань (8512)99-46-04  
Барнаул (3852)73-04-60  
Белгород (4722)40-23-64  
Благовещенск (4162)22-76-07  
Брянск (4832)59-03-52  
Владивосток (423)249-28-31  
Владикавказ (8672)28-90-48  
Владимир (4922)49-43-18  
Волгоград (844)278-03-48  
Вологда (8172)26-41-59  
Воронеж (473)204-51-73  
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06  
Ижевск (3412)26-03-58  
Иркутск (395)279-98-46  
Казань (843)206-01-48  
Калининград (4012)72-03-81  
Калуга (4842)92-23-67  
Кемерово (3842)65-04-62  
Киров (8332)68-02-04  
Коломна (4966)23-41-49  
Кострома (4942)77-07-48  
Краснодар (861)203-40-90  
Красноярск (391)204-63-61  
Курск (4712)77-13-04  
Курган (3522)50-90-47  
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13  
Москва (495)268-04-70  
Мурманск (8152)59-64-93  
Набережные Челны (8552)20-53-41  
Нижний Новгород (831)429-08-12  
Новокузнецк (3843)20-46-81  
Ноябрьск (3496)41-32-12  
Новосибирск (383)227-86-73  
Омск (3812)21-46-40  
Орел (4862)44-53-42  
Оренбург (3532)37-68-04  
Пенза (8412)22-31-16  
Петрозаводск (8142)55-98-37  
Псков (8112)59-10-37  
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15  
Рязань (4912)46-61-64  
Самара (846)206-03-16  
Санкт-Петербург (812)309-46-40  
Саратов (845)249-38-78  
Севастополь (8692)22-31-93  
Саранск (8342)22-96-24  
Симферополь (3652)67-13-56  
Смоленск (4812)29-41-54  
Сочи (862)225-72-31  
Ставрополь (8652)20-65-13  
Сургут (3462)77-98-35  
Сыктывкар (8212)25-95-17  
Тамбов (4752)50-40-97  
Тверь (4822)63-31-35

Тольятти (8482)63-91-07  
Томск (3822)98-41-53  
Тула (4872)33-79-87  
Тюмень (3452)66-21-18  
Ульяновск (8422)24-23-59  
Улан-Удэ (3012)59-97-51  
Уфа (347)229-48-12  
Хабаровск (4212)92-98-04  
Чебоксары (8352)28-53-07  
Челябинск (351)202-03-61  
Череповец (8202)49-02-64  
Чита (3022)38-34-83  
Якутск (4112)23-90-97  
Ярославль (4852)69-52-93

Россия +7(495)268-04-70



















Казахстан +(727)345-47-04





















Беларусь +(375)257-127-884





















Узбекистан +998(71)205-18-59





















Киргизия +996(312)96-26-47

эл.почта: [tuq@nt-rt.ru](mailto:tuq@nt-rt.ru) || сайт: <https://telemecanique.nt-rt.ru>







	<a href="#"><u>XY2CEIA590</u></a>	Latching emergency stop rope pull switch, Telemecanique rope pull switches XY2C, cable XY2CE, 300 V AC, 10 A
	<a href="#"><u>XY2CEIC250H7TK</u></a>	Latching emergency stop rope pull switch, Telemecanique rope pull switches XY2C, CABLE 300 V AC, 10 A, red RAL 3000
	<a href="#"><u>XY2CEIC250TK</u></a>	Latching emergency stop rope pull switch, Telemecanique rope pull switches XY2C, cable XY2CE, 300 V AC, 10 A
	<a href="#"><u>XY2CEIC270TK</u></a>	Latching emergency stop rope pull switch, Telemecanique rope pull switches XY2C, cable XY2CE, 300 V AC, 10 A
	<a href="#"><u>XY2CEIC290</u></a>	Latching emergency stop rope pull switch, Telemecanique rope pull switches XY2C, cable XY2CE, 300 V AC, 10 A
	<a href="#"><u>XY2CEIC290TK</u></a>	Latching emergency stop rope pull switch, Telemecanique rope pull switches XY2C, trip wire cable 300 VAC 10 A XY2CE
	<a href="#"><u>XY2CEIC296TK</u></a>	Latching emergency stop rope pull switch, Telemecanique rope pull switches XY2C, cable XY2CE, 300 V AC, 10 A
	<a href="#"><u>XY2CEIC496TK</u></a>	Latching emergency stop rope pull switch, Telemecanique rope pull switches XY2C, cable XY2CE, 300 V AC, 10 A
	<a href="#"><u>XY2CEID290</u></a>	Latching emergency stop rope pull switch, Telemecanique rope pull switches XY2C, cable XY2CE, 300 V AC, 10 A
	<a href="#"><u>XY2CD01</u></a>	Head for simple rope pull switch, Telemecanique Emergency stop rope pull switches XY2C, XY2CdII cable sw 240 VAC 10 A
	<a href="#"><u>XY2CDIII</u></a>	Simple rope pull switch, Telemecanique Emergency stop rope pull switches XY2C, cable 240 VAC 10 A XY2Cd
	<a href="#"><u>XY2CDIIIH29</u></a>	Simple rope pull switch, Telemecanique Emergency stop rope pull switches XY2C, INC + 1 NO, snap action, 240 VAC, 10 A, XY2CD
	<a href="#"><u>XY2CD433180</u></a>	Simple rope pull switch, Telemecanique Emergency stop rope pull switches XY2C, 10 A, 3 cable entry
	<a href="#"><u>XY2CEIA150H7</u></a>	Latching emergency stop rope pull switch, Telemecanique rope pull switches XY2C, e XY2CE, RH side -INC+1 NO, Flush pushbutton
	<a href="#"><u>XY2CEIA150H7</u></a>	Latching emergency stop rope pull switch, Telemecanique rope pull switches XY2C, e XY2CE, RH side -INC+1 NO, Flush pushbutton
	<a href="#"><u>XY2CEIA190H7</u></a>	Latching emergency stop rope pull switch, Telemecanique rope pull switches XY2C, cable 300 VAC 10amp XY2CE+options
	<a href="#"><u>XY2CEIA196</u></a>	Latching emergency stop rope pull switch, Telemecanique rope pull switches XY2C, trip wire cable 300 VAC 10 A XY2CE
	<a href="#"><u>XY2CEIA196H7</u></a>	Latching emergency stop rope pull switch, Telemecanique rope pull switches XY2C, cable 300 VAC 10amp XY2CE+options

























	<a href="#">XY2CEIE296TK</a>	Latching emergency stop rope pull switch, Telemecanique rope pull switches XY2C, cable XY2CE, 300 V AC, 10 A
	<a href="#">XY2CE2A150H7</a>	Latching emergency stop rope pull switch, Telemecanique rope pull switches XY2C, e XY2CE, LH side -INC+1 NO, Flush pushbutton
	<a href="#">XY2CE2A150H7</a>	Latching emergency stop rope pull switch, Telemecanique rope pull switches XY2C, e XY2CE, LH side -INC+1 NO, Flush pushbutton
	<a href="#">XY2CE2A190H7</a>	Latching emergency stop rope pull switch, Telemecanique rope pull switches XY2C, cable 300 VAC 10amp XY2CE+options
	<a href="#">XY2CE2A196</a>	Latching emergency stop rope pull switch, Telemecanique rope pull switches XY2C, trip wire cable 300 VAC 10 A XY2CE
	<a href="#">XY2CE2A196H7</a>	Latching emergency stop rope pull switch, Telemecanique rope pull switches XY2C, cable 300 VAC 10amp XY2CE+options
	<a href="#">XY2CE2A296FWB24</a>	Latching emergency stop rope pull switch, Telemecanique rope pull switches XY2C, cable XY2CE, 300 V AC, 10 A
	<a href="#">XY2CE2A396</a>	Latching emergency stop rope pull switch, Telemecanique rope pull switches XY2C, trip wire cable 300 VAC 10 A XY2CE
	<a href="#">XY2CE2A450H7</a>	Latching emergency stop rope pull switch, Telemecanique rope pull switches XY2C, cable XY2CE, 300 V AC, 10 A
	<a href="#">XY2CE2A496</a>	Latching emergency stop rope pull switch, Telemecanique rope pull switches XY2C, simple reset by flush push button
	<a href="#">XY2CE2A570</a>	Latching emergency stop rope pull switch, Telemecanique rope pull switches XY2C, simple reset by flush push button
	<a href="#">XY2CE2A590</a>	Latching emergency stop rope pull switch, Telemecanique rope pull switches XY2C, cable XY2CE, 300 V AC, 10 A
	<a href="#">XY2CE2C250</a>	Latching emergency stop rope pull switch, Telemecanique rope pull switches XY2C, simple reset by flush push button
	<a href="#">XY2CE2C250TK</a>	Latching emergency stop rope pull switch, Telemecanique rope pull switches XY2C, cable XY2CE, 300 V AC, 10 A
	<a href="#">XY2CE2C270TK</a>	Latching emergency stop rope pull switch, Telemecanique rope pull switches XY2C, cable XY2CE, 300 V AC, 10 A
	<a href="#">XY2CE2C290</a>	Latching emergency stop rope pull switch, Telemecanique rope pull switches XY2C, simple reset by flush push button
	<a href="#">XY2CE2C290TK</a>	Latching emergency stop rope pull switch, Telemecanique rope pull switches XY2C, simple reset by flush push button
	<a href="#">XY2CE2C296</a>	Latching emergency stop rope pull switch, Telemecanique rope pull switches XY2C, simple reset by flush push button
	<a href="#">XY2CE2C296TK</a>	Latching emergency stop rope pull switch, Telemecanique rope pull switches XY2C, simple reset by flush push button
	<a href="#">XY2CE2C396TK</a>	Latching emergency stop rope pull switch, Telemecanique Emergency stop rope pull switches XY2C, without pilot light












	<a href="#"><u>XY2CE2C570TK</u></a>	Latching emergency stop rope pull switch, Telemecanique Emergency stop rope pull switches XY2C, e XY2C, Flush pushbutton
	<a href="#"><u>XY2CE2C596</u></a>	Latching emergency stop rope pull switch, Telemecanique rope pull switches XY2C, simple reset by flush push button
	<a href="#"><u>XY2CE2D290</u></a>	Latching emergency stop rope pull switch, Telemecanique Emergency stop rope pull switches XY2C, e XY2C, Flush pushbutton
	<a href="#"><u>XY2CE2D296</u></a>	Latching emergency stop rope pull switch, Telemecanique Emergency stop rope pull switches XY2C, simple reset by flush push button
	<a href="#"><u>XY2CE2D297</u></a>	Latching emergency stop rope pull switch, Telemecanique Emergency stop rope pull switches XY2C, simple reset by flush push button
	<a href="#"><u>XY2CE3A010</u></a>	Simple emergency stop rope pull switch, Telemecanique rope pull switches XY2C, XY2CE, RH side, 1NC+1 NO
	<a href="#"><u>XY2CE3A010H7</u></a>	Latching emergency stop rope pull switch, Telemecanique rope pull switches XY2C, cable XY2CE, 300 V AC, 10 A
	<a href="#"><u>XY2CE3A010S02</u></a>	Latching emergency stop rope pull switch, Telemecanique Emergency stop rope pull switches XY2C, trip wire anchor right
	<a href="#"><u>XY2CE3A020</u></a>	Latching emergency stop rope pull switch, Telemecanique rope pull switches XY2C, cable XY2CE, 300 V AC, 10 A
	<a href="#"><u>XY2CE4A010</u></a>	Simple emergency stop rope pull switch, Telemecanique rope pull switches XY2C, e XY2CE, LH side, 1NC+1 NO
	<a href="#"><u>XY2CE5A297</u></a>	Latching emergency stop rope pull switch, Telemecanique rope pull switches XY2C, simple reset by flush push button
	<a href="#"><u>XY2CE6A270</u></a>	Latching emergency stop rope pull switch, Telemecanique rope pull switches XY2C, simple reset by flush push button
	<a href="#"><u>XY2CE6A290</u></a>	Latching emergency stop rope pull switch, Telemecanique Emergency stop rope pull switches XY2C, simple reset by flush push button
	<a href="#"><u>XY2CE6A296</u></a>	Latching emergency stop rope pull switch, Telemecanique rope pull switches XY2C, simple reset by flush push button
	<a href="#"><u>XY2CE6A297</u></a>	Latching emergency stop rope pull switch, Telemecanique rope pull switches XY2C, simple reset by flush push button
	<a href="#"><u>XY2CH33010</u></a>	Simple stop rope pull switch, Telemecanique Emergency stop rope pull switches XY2C, e XY2CH, 1NC+1 NO
	<a href="#"><u>XY2CZ1015</u></a>	Telemecanique Emergency stop rope pull switches XY2C, red galvanised cable, Ø 5 mm, L 15.5 m, for XY2C
	<a href="#"><u>XY2CZ1015</u></a>	Telemecanique Emergency stop rope pull switches XY2C, red galvanised cable, Ø 5 mm, L 15.5 m, for XY2C
	<a href="#"><u>XY2CZ102</u></a>	Telemecanique Emergency stop rope pull switches XY2C, red galvanised cable, Ø 5 mm, L 25.5 m, for XY2C
	<a href="#"><u>XY2CZ102</u></a>	Telemecanique Emergency stop rope pull switches XY2C, red galvanised cable, Ø 5 mm, L 25.5 m, for XY2C

	<a href="#">XY2CE4A010H7</a>	Latching emergency stop rope pull switch, Telemecanique rope pull switches XY2C, cable XY2CE, 300 V AC, 10 A
	<a href="#">XY2CE4A010S02</a>	Latching emergency stop rope pull switch, Telemecanique Emergency stop rope pull switches XY2C, trip wire anchor left
	<a href="#">XY2CE4A020</a>	Latching emergency stop rope pull switch, Telemecanique rope pull switches XY2C, cable XY2CE, 300 V AC, 10 A
	<a href="#">XY2CE4A020H7</a>	Cable pull switch 300 VAC 10 A XY2CE
	<a href="#">XY2CE4C010TK</a>	Latching emergency stop rope pull switch, Telemecanique rope pull switches XY2C, cable XY2CE, 300 V AC, 10 A
	<a href="#">XY2CE5A250</a>	Latching emergency stop rope pull switch, Telemecanique rope pull switches XY2C, simple reset by flush push button
	<a href="#">XY2CE5A270</a>	Latching emergency stop rope pull switch, Telemecanique rope pull switches XY2C, simple reset by flush push button
	<a href="#">XY2CE5A270H7</a>	Latching emergency stop rope pull switch, Telemecanique rope pull switches XY2C, cable anchor right
	<a href="#">XY2CE5A290</a>	Latching emergency stop rope pull switch, Telemecanique Emergency stop rope pull switches XY2C, simple reset by flush push button
	<a href="#">XY2CE5A296</a>	Latching emergency stop rope pull switch, Telemecanique rope pull switches XY2C, simple reset by flush push button
	<a href="#">XY2CZ105</a>	Telemecanique Emergency stop rope pull switches XY2C, red galvanised cable, Ø 5 mm, L 50.5 m, for XY2C
	<a href="#">XY2CZ105</a>	Telemecanique Emergency stop rope pull switches XY2C, red galvanised cable, Ø 5 mm, L 50.5 m, for XY2C
	<a href="#">XY2CZ107</a>	Telemecanique Emergency stop rope pull switches XY2C, red galvanised cable, Ø 5 mm, L 70.5 m, for XY2C
	<a href="#">XY2CZ107</a>	Telemecanique Emergency stop rope pull switches XY2C, red galvanised cable, Ø 5 mm, L 70.5 m, for XY2C
	<a href="#">XY2CZ110</a>	Telemecanique Emergency stop rope pull switches XY2C, red galvanised cable, Ø 5 mm, L 100.5 m, for XY2C
	<a href="#">XY2CZ110</a>	Telemecanique Emergency stop rope pull switches XY2C, red galvanised cable, Ø 5 mm, L 100.5 m, for XY2C
	<a href="#">XY2CZ301</a>	Telemecanique Emergency stop rope pull switches XY2C, red galvanised cable, Ø 3.2 mm, L 10.5 m, for XY2C
	<a href="#">XY2CZ301</a>	Telemecanique Emergency stop rope pull switches XY2C, red galvanised cable, Ø 3.2 mm, L 10.5 m, for XY2C
	<a href="#">XY2CZ3015</a>	Telemecanique Emergency stop rope pull switches XY2C, red galvanised cable, Ø 3.2 mm, L 15.5 m, for XY2C
	<a href="#">XY2CZ3015</a>	Telemecanique Emergency stop rope pull switches XY2C, red galvanised cable, Ø 3.2 mm, L 15.5 m, for XY2C



	<a href="#"><u>XY2CZ302</u></a>	Telemecanique Emergency stop rope pull switches XY2C, red galvanised cable, Ø 3.2 mm, L 25.5 m, for XY2C
	<a href="#"><u>XY2CZ302</u></a>	Telemecanique Emergency stop rope pull switches XY2C, red galvanised cable, Ø 3.2 mm, L 25.5 m, for XY2C
	<a href="#"><u>XY2CZ303</u></a>	Telemecanique Emergency stop rope pull switches XY2C, red galvanised cable, Ø 3.2 mm, L 30.5 m, for XY2C
	<a href="#"><u>XY2CZ303</u></a>	Telemecanique Emergency stop rope pull switches XY2C, red galvanised cable, Ø 3.2 mm, L 30.5 m, for XY2C
	<a href="#"><u>XY2CZ305</u></a>	Telemecanique Emergency stop rope pull switches XY2C, red galvanised cable, Ø 3.2 mm, L 50.5 m, for XY2C
	<a href="#"><u>XY2CZ310</u></a>	Telemecanique Emergency stop rope pull switches XY2C, red galvanised cable, Ø 3.2 mm, L 100.5 m, for XY2C
	<a href="#"><u>XY2CZ402</u></a>	Telemecanique Emergency stop rope pull switches XY2C, turnbuckle M6, for XY2C
	<a href="#"><u>XY2CZ402</u></a>	Telemecanique Emergency stop rope pull switches XY2C, turnbuckle M6, for XY2C
	<a href="#"><u>XY2CZ404</u></a>	Telemecanique Emergency stop rope pull switches XY2C, turnbuckle M8, for XY2C
	<a href="#"><u>XY2CZ404</u></a>	Telemecanique Emergency stop rope pull switches XY2C, turnbuckle M8, for XY2C
	<a href="#"><u>XY2CZ404</u></a>	Telemecanique Emergency stop rope pull switches XY2C, turnbuckle M8, for XY2C
	<a href="#"><u>XY2CZ503</u></a>	Telemecanique Emergency stop rope pull switches XY2C, single cable grip, cable Ø 3 to 5 mm, for XY2C
	<a href="#"><u>XY2CZ503</u></a>	Telemecanique Emergency stop rope pull switches XY2C, single cable grip, cable Ø 3 to 5 mm, for XY2C
	<a href="#"><u>XY2CZ513</u></a>	Telemecanique Emergency stop rope pull switches XY2C, double cable grip, cable Ø 3 to 5 mm, for XY2C
	<a href="#"><u>XY2CZ513</u></a>	Telemecanique Emergency stop rope pull switches XY2C, double cable grip, cable Ø 3 to 5 mm, for XY2C
	<a href="#"><u>XY2CZ523</u></a>	Telemecanique Emergency stop rope pull switches XY2C, cable clamp, Ø 3.2 mm, for XY2C
	<a href="#"><u>XY2CZ523</u></a>	Telemecanique Emergency stop rope pull switches XY2C, cable clamp, Ø 3.2 mm, for XY2C
	<a href="#"><u>XY2CZ524</u></a>	Telemecanique Emergency stop rope pull switches XY2C, cable clamp, Ø 5 mm, for XY2C
	<a href="#"><u>XY2CZ524</u></a>	Telemecanique Emergency stop rope pull switches XY2C, cable clamp, Ø 5 mm, for XY2C
	<a href="#"><u>XY2CZ601</u></a>	Telemecanique Emergency stop rope pull switches XY2C, fixed cable support, for XY2C
	<a href="#"><u>XY2CZ601</u></a>	Telemecanique Emergency stop rope pull switches XY2C, fixed cable support, for XY2C

	<a href="#">XY2CZ602</a>	Telemecanique Emergency stop rope pull switches XY2C, swivelling cable support, for XY2C
	<a href="#">XY2CZ602</a>	Telemecanique Emergency stop rope pull switches XY2C, swivelling cable support, for XY2C
	<a href="#">XY2CZ701</a>	Telemecanique Emergency stop rope pull switches XY2C, cable end protector, Ø 3.2 mm, for XY2C
	<a href="#">XY2CZ701</a>	Telemecanique Emergency stop rope pull switches XY2C, cable end protector, Ø 3.2 mm, for XY2C
	<a href="#">XY2CZ702</a>	Telemecanique Emergency stop rope pull switches XY2C, end spring, for XY2CE
	<a href="#">XY2CZ702</a>	Telemecanique Emergency stop rope pull switches XY2C, end spring, for XY2CE
	<a href="#">XY2CZ703</a>	Telemecanique Emergency stop rope pull switches XY2C, end spring, for XY2CH
	<a href="#">XY2CZ703</a>	Telemecanique Emergency stop rope pull switches XY2C, end spring, for XY2CH
	<a href="#">XY2CZ704</a>	Telemecanique Emergency stop rope pull switches XY2C, cable end protector, Ø 5 mm, for XY2C
	<a href="#">XY2CZ704</a>	Telemecanique Emergency stop rope pull switches XY2C, cable end protector, Ø 5 mm, for XY2C
	<a href="#">XY2CZ705</a>	Telemecanique Emergency stop rope pull switches XY2C, pulley bracket, for XY2CH XY2CE
	<a href="#">XY2CZ9310</a>	Telemecanique Emergency stop rope pull switches XY2C, mounting kit, Ø 3.2 mm, L 10.5 m
	<a href="#">XY2CZ9310</a>	Telemecanique Emergency stop rope pull switches XY2C, mounting kit, Ø 3.2 mm, L 10.5 m
	<a href="#">XY2CZ9315</a>	Telemecanique Emergency stop rope pull switches XY2C, mounting kit, Ø 3.2 mm, L 15.5 m
	<a href="#">XY2CZ9315</a>	Telemecanique Emergency stop rope pull switches XY2C, mounting kit, Ø 3.2 mm, L 15.5 m
	<a href="#">XY2CZ9330</a>	Telemecanique Emergency stop rope pull switches XY2C, mounting kit, Ø 3.2 mm, L 30.5 m
	<a href="#">XY2CZ9330</a>	Telemecanique Emergency stop rope pull switches XY2C, mounting kit, Ø 3.2 mm, L 30.5 m
	<a href="#">XY2CZ9350</a>	Telemecanique Emergency stop rope pull switches XY2C, mounting kit, Ø 3.2 mm, L 50.5 m
	<a href="#">XY2CZ9525</a>	Telemecanique Emergency stop rope pull switches XY2C, mounting kit, Ø 5 mm, L 25.5 m
	<a href="#">XY2CZ9525</a>	Telemecanique Emergency stop rope pull switches XY2C, mounting kit, Ø 5 mm, L 25.5 m
	<a href="#">XY2CZ9550</a>	Telemecanique Emergency stop rope pull switches XY2C, mounting kit, Ø 5 mm, L 50.5 m
	<a href="#">XY2CZ9550</a>	Telemecanique Emergency stop rope pull switches XY2C, mounting kit, Ø 5 mm, L 50.5 m
	<a href="#">XY2CZ9570</a>	Telemecanique Emergency stop rope pull switches XY2C, mounting kit, Ø 5 mm, L 70.5 m
	<a href="#">XY2CZ9570</a>	Telemecanique Emergency stop rope pull switches XY2C, mounting kit, Ø 5 mm, L 70.5 m

	<a href="#"><u>XY2CZ704</u></a>	Telemecanique Emergency stop rope pull switches XY2C, cable end protector, Ø 5 mm, for XY2C
	<a href="#"><u>XY2CZ705</u></a>	Telemecanique Emergency stop rope pull switches XY2C, pulley bracket, for XY2CH XY2CE
	<a href="#"><u>XY2CZ705</u></a>	Telemecanique Emergency stop rope pull switches XY2C, pulley bracket, for XY2CH XY2CE
	<a href="#"><u>XY2CZ708</u></a>	Telemecanique Emergency stop rope pull switches XY2C, pulley for cable Ø 5 mm maximum, for XY2C
	<a href="#"><u>XY2CZ708</u></a>	Telemecanique Emergency stop rope pull switches XY2C, pulley for cable Ø 5 mm maximum, for XY2C
	<a href="#"><u>XY2CZ800</u></a>	Pilot light lens, Telemecanique Emergency stop rope pull switches XY2C, head, red, for XY2CE
	<a href="#"><u>XY2CZ800</u></a>	Pilot light lens, Telemecanique Emergency stop rope pull switches XY2C, head, red, for XY2CE
	<a href="#"><u>XY2CZ801</u></a>	Pilot light lens, Telemecanique Emergency stop rope pull switches XY2C, head, orange, for XY2CE
	<a href="#"><u>XY2CZ801</u></a>	Pilot light lens, Telemecanique Emergency stop rope pull switches XY2C, head, orange, for XY2CE
	<a href="#"><u>XY2CZ918</u></a>	Telemecanique Emergency stop rope pull switches XY2C, mounting kit, spring notched washer circlip
	<a href="#"><u>XY2CZ918</u></a>	Telemecanique Emergency stop rope pull switches XY2C, mounting kit, spring notched washer circlip



## По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04  
Ангарск (3955)60-70-56  
Архангельск (8182)63-90-72  
Астрахань (8512)99-46-04  
Барнаул (3852)73-04-60  
Белгород (4722)40-23-64  
Благовещенск (4162)22-76-07  
Брянск (4832)59-03-52  
Владивосток (423)249-28-31  
Владикавказ (8672)28-90-48  
Владимир (4922)49-43-18  
Волгоград (844)278-03-48  
Вологда (8172)26-41-59  
Воронеж (473)204-51-73  
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06  
Ижевск (3412)26-03-58  
Иркутск (395)279-98-46  
Казань (843)206-01-48  
Калининград (4012)72-03-81  
Калуга (4842)92-23-67  
Кемерово (3842)65-04-62  
Киров (8332)68-02-04  
Коломна (4966)23-41-49  
Кострома (4942)77-07-48  
Краснодар (861)203-40-90  
Красноярск (391)204-63-61  
Курск (4712)77-13-04  
Курган (3522)50-90-47  
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13  
Москва (495)268-04-70  
Мурманск (8152)59-64-93  
Набережные Челны (8552)20-53-41  
Новокузнецк (3843)20-46-81  
Ноябрьск (3496)41-32-12  
Новосибирск (383)227-86-73  
Омск (3812)21-46-40  
Орел (4862)44-53-42  
Оренбург (3532)37-68-04  
Пенза (8412)22-31-16  
Петрозаводск (8142)55-98-37  
Псков (8112)59-10-37  
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15  
Рязань (4912)46-61-64  
Самара (846)206-03-16  
Санкт-Петербург (812)309-46-40  
Саратов (845)249-38-78  
Севастополь (8692)22-31-93  
Саранск (8342)22-96-24  
Симферополь (3652)67-13-56  
Смоленск (4812)29-41-54  
Сочи (862)225-72-31  
Ставрополь (8652)20-65-13  
Сургут (3462)77-98-35  
Сыктывкар (8212)25-95-17  
Тамбов (4752)50-40-97  
Тверь (4822)63-31-35

Тольятти (8482)63-91-07  
Томск (3822)98-41-53  
Тула (4872)33-79-87  
Тюмень (3452)66-21-18  
Ульяновск (8422)24-23-59  
Улан-Удэ (3012)59-97-51  
Уфа (347)229-48-12  
Хабаровск (4212)92-98-04  
Чебоксары (8352)28-53-07  
Челябинск (351)202-03-61  
Череповец (8202)49-02-64  
Чита (3022)38-34-83  
Якутск (4112)23-90-97  
Ярославль (4852)69-52-93

**Россия** +7(495)268-04-70

**Казахстан** +(727)345-47-04

**Беларусь** +(375)257-127-884

**Узбекистан** +998(71)205-18-59

**Киргизия** +996(312)96-26-47

эл.почта: [tuq@nt-rt.ru](mailto:tuq@nt-rt.ru) || сайт: <https://telemecanique.nt-rt.ru>