

# Аксессуары

## Технические характеристики

По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04  
Ангарск (3955)60-70-56  
Архангельск (8182)63-90-72  
Астрахань (8512)99-46-04  
Барнаул (3852)73-04-60  
Белгород (4722)40-23-64  
Благовещенск (4162)22-76-07  
Брянск (4832)59-03-52  
Владивосток (423)249-28-31  
Владикавказ (8672)28-90-48  
Владимир (4922)49-43-18  
Волгоград (844)278-03-48  
Вологда (8172)26-41-59  
Воронеж (473)204-51-73  
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06  
Ижевск (3412)26-03-58  
Иркутск (395)279-98-46  
Казань (843)206-01-48  
Калининград (4012)72-03-81  
Калуга (4842)92-23-67  
Кемерово (3842)65-04-62  
Киров (8332)68-02-04  
Коломна (4966)23-41-49  
Кострома (4942)77-07-48  
Краснодар (861)203-40-90  
Красноярск (391)204-63-61  
Курск (4712)77-13-04  
Курган (3522)50-90-47  
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13  
Москва (495)268-04-70  
Мурманск (8152)59-64-93  
Набережные Челны (8552)20-53-41  
Нижний Новгород (831)429-08-12  
Новокузнецк (3843)20-46-81  
Ноябрьск (3496)41-32-12  
Новосибирск (383)227-86-73  
Омск (3812)21-46-40  
Орел (4862)44-53-42  
Оренбург (3532)37-68-04  
Пенза (8412)22-31-16  
Петрозаводск (8142)55-98-37  
Псков (8112)59-10-37  
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15  
Рязань (4912)46-61-64  
Самара (846)206-03-16  
Санкт-Петербург (812)309-46-40  
Саратов (845)249-38-78  
Севастополь (8692)22-31-93  
Саранск (8342)22-96-24  
Симферополь (3652)67-13-56  
Смоленск (4812)29-41-54  
Сочи (862)225-72-31  
Ставрополь (8652)20-65-13  
Сургут (3462)77-98-35  
Сыктывкар (8212)25-95-17  
Тамбов (4752)50-40-97  
Тверь (4822)63-31-35

Тольятти (8482)63-91-07  
Томск (3822)98-41-53  
Тула (4872)33-79-87  
Тюмень (3452)66-21-18  
Ульяновск (8422)24-23-59  
Улан-Удэ (3012)59-97-51  
Уфа (347)229-48-12  
Хабаровск (4212)92-98-04  
Чебоксары (8352)28-53-07  
Челябинск (351)202-03-61  
Череповец (8202)49-02-64  
Чита (3022)38-34-83  
Якутск (4112)23-90-97  
Ярославль (4852)69-52-93

Россия +7(495)268-04-70





















Казахстан +(727)345-47-04















Беларусь +(375)257-127-884

Узбекистан +998(71)205-18-59

Киргизия +996(312)96-26-47

эл.почта: [tuq@nt-rt.ru](mailto:tuq@nt-rt.ru) || сайт: <https://telemecanique.nt-rt.ru>

	<a href="#"><u>TCSCTN01IM1F</u></a>	Radio frequency identification XG, Network connector, RS485 network or CANopen, M12, 5 pin 1 male/ 2 female
	<a href="#"><u>TCSMCNIF10</u></a>	Radio frequency identification XG, Modbus shielded cable, M12 female connector, end with free wires, IP67, 10 m
	<a href="#"><u>TCSMCNIF2</u></a>	Radio frequency identification XG, Modbus shielded cable, M12 female connector, end with free wires, IP67, 2 m
	<a href="#"><u>TCSMCNIF5</u></a>	Radio frequency identification XG, Modbus shielded cable, M12 female connector, end with free wires, IP67, 5 m
	<a href="#"><u>TCSMCNIM1F1</u></a>	Radio frequency identification XG, Modbus shielded cable, M12 male connector, M12 female connector, IP67, 1 m
	<a href="#"><u>TCSMCNIM1F10</u></a>	Radio frequency identification XG, Modbus shielded cable, M12 male connector, M12 female connector, IP67, 10 m
	<a href="#"><u>TCSMCNIM1F2</u></a>	Radio frequency identification XG, Modbus shielded cable, M12 male connector, M12 female connector, IP67, 2 m
	<a href="#"><u>TCSMCNIM1F5</u></a>	Radio frequency identification XG, Modbus shielded cable, M12 male connector, M12 female connector, IP67, 5 m
	<a href="#"><u>XGFEC2525</u></a>	Radio frequency identification XG, field expander universal type, Sn 26...150 mm, 250 x 250 x 10 mm
	<a href="#"><u>XGFEC520</u></a>	Radio frequency identification XG, field expander, 200 mm x 23 mm x 50 mm, for station with associated label
	<a href="#"><u>XGFEC530</u></a>	Radio frequency identification XG, rfid field expander 5x30
	<a href="#"><u>XGFEC540</u></a>	Radio frequency identification XG, field expander conveying type, Sn 30...90 mm, 400 x 23 x 50 mm
	<a href="#"><u>XGSZ09L10</u></a>	Radio frequency identification XG, pre wired M12 female connector, cable 10 m, IP67
	<a href="#"><u>XGSZ09L2</u></a>	Radio frequency identification XG, pre wired M12 female connector, cable 2 m, IP67
	<a href="#"><u>XGSZ12E1203</u></a>	Ethernet copper cable, Radio frequency identification XG, M12/M12 D coded, 3 m
	<a href="#"><u>XGSZ12E1210</u></a>	Ethernet copper cable, Radio frequency identification XG, M12/M12 D coded, 10 m
	<a href="#"><u>XGSZ12E4503</u></a>	Ethernet copper cable, Radio frequency identification XG, M12 D coded to RJ45, 3 m
	<a href="#"><u>XGSZ12E4510</u></a>	Ethernet copper cable, Radio frequency identification XG, M12 D coded to RJ45, 10 m
	<a href="#"><u>XGSZ22E4503</u></a>	Ethernet copper cable, Radio frequency identification XG, Jumper M12/RJ45 straight/elbowed shielded 3 m
	<a href="#"><u>XGSZ22E4510</u></a>	Ethernet copper cable, Radio frequency identification XG, Jumper M12/RJ45 straight/elbowed shielded 10 m

	<a href="#"><b>XGSZ24</b></a>	RS232/RS485 interface, Radio frequency identification XG, RS 232/RS 485 line adaptor, for XGS K, XGS D
	<a href="#"><b>XGSZCNF01</b></a>	Configuration badge, Radio frequency identification XG, for of RFID sation addresses
	<a href="#"><b>XZCC12FDB50R</b></a>	Female, M12, 5 pin, shielded straight connector
	<a href="#"><b>XZCC12FDM40B</b></a>	Female, M12, 4 pin, straight connector, cable gland Pg 7
	<a href="#"><b>XZCC12MDB50R</b></a>	Male, M12, 5 pin, shielded straight connector
	<a href="#"><b>XZCP0941L10</b></a>	Pre wired connectors XZ, straight female, M8, 4 pins, cable PUR 10 m
	<a href="#"><b>XZCP0941L2</b></a>	Pre wired connectors XZ, straight female, M8, 4 pins, cable PUR 2 m
	<a href="#"><b>XZCP0941L5</b></a>	Pre wired connectors XZ, straight female, M8, 4 pins, cable PUR 5 m
	<a href="#"><b>XZCPV11V2L10</b></a>	Pre wired connectors XZ, straight female, M12, 3 wires, cable 10 m
	<a href="#"><b>XZCPV11V2L2</b></a>	Pre wired connectors XZ, straight female, M12, 3 wires, cable 2 m
	<a href="#"><b>XZCPV11V2L5</b></a>	Pre wired connectors XZ, straight female, M12, 3 wires, cable 5 m
	<a href="#"><b>XZCPV12V2L10</b></a>	Pre wired connectors XZ, elbowed female, M12, 3 wires, cable 10 m
	<a href="#"><b>XZCPV12V2L2</b></a>	Pre wired connectors XZ, elbowed female, M12, 3 wires, cable 2 m
	<a href="#"><b>XZCPV12V2L5</b></a>	Pre wired connectors XZ, elbowed female, M12, 3 wires, cable 5 m

## По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04  
Ангарск (3955)60-70-56  
Архангельск (8182)63-90-72  
Астрахань (8512)99-46-04  
Барнаул (3852)73-04-60  
Белгород (4722)40-23-64  
Благовещенск (4162)22-76-07  
Брянск (4832)59-03-52  
Владивосток (423)249-28-31  
Владикавказ (8672)28-90-48  
Владимир (4922)49-43-18  
Волгоград (844)278-03-48  
Вологда (8172)26-41-59  
Воронеж (473)204-51-73  
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06  
Ижевск (3412)26-03-58  
Иркутск (395)279-98-46  
Казань (843)206-01-48  
Калининград (4012)72-03-81  
Калуга (4842)92-23-67  
Кемерово (3842)65-04-62  
Киров (8332)68-02-04  
Коломна (4966)23-41-49  
Кострома (4942)77-07-48  
Краснодар (861)203-40-90  
Красноярск (391)204-63-61  
Курск (4712)77-13-04  
Курган (3522)50-90-47  
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13  
Москва (495)268-04-70  
Мурманск (8152)59-64-93  
Набережные Челны (8552)20-53-41  
Новокузнецк (3843)20-46-81  
Ноябрьск (3496)41-32-12  
Новосибирск (383)227-86-73  
Омск (3812)21-46-40  
Орел (4862)44-53-42  
Оренбург (3532)37-68-04  
Пенза (8412)22-31-16  
Петрозаводск (8142)55-98-37  
Псков (8112)59-10-37  
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15  
Рязань (4912)46-61-64  
Самара (846)206-03-16  
Санкт-Петербург (812)309-46-40  
Саратов (845)249-38-78  
Севастополь (8692)22-31-93  
Саранск (8342)22-96-24  
Симферополь (3652)67-13-56  
Смоленск (4812)29-41-54  
Сочи (862)225-72-31  
Ставрополь (8652)20-65-13  
Сургут (3462)77-98-35  
Сыктывкар (8212)25-95-17  
Тамбов (4752)50-40-97  
Тверь (4822)63-31-35

Тольятти (8482)63-91-07  
Томск (3822)98-41-53  
Тула (4872)33-79-87  
Тюмень (3452)66-21-18  
Ульяновск (8422)24-23-59  
Улан-Удэ (3012)59-97-51  
Уфа (347)229-48-12  
Хабаровск (4212)92-98-04  
Чебоксары (8352)28-53-07  
Челябинск (351)202-03-61  
Череповец (8202)49-02-64  
Чита (3022)38-34-83  
Якутск (4112)23-90-97  
Ярославль (4852)69-52-93

**Россия** +7(495)268-04-70

**Казахстан** +(727)345-47-04

**Беларусь** +(375)257-127-884

**Узбекистан** +998(71)205-18-59

**Киргизия** +996(312)96-26-47

эл.почта: [tuq@nt-rt.ru](mailto:tuq@nt-rt.ru) || сайт: <https://telemecanique.nt-rt.ru>